



27-ая Международная Встреча воздухоплавателей в Великих Луках 11-17 июня 2023 г.



НАСТРОЙКИ GPS-ЛОГГЕРА:

- интервал времени: **1 секунда**
- высота: **GPS**
- единица измерения высоты: **фут**
- дата/время: **местное время**
- установки (датум) карты: **WGS84 / UTM**
- WAAS: **Включено/enabled**
- ГЛОНАСС: **Включено/enabled**

ПРИЛОЖЕНИЕ BALLOONLIVE

- дать приложению все требуемые разрешения (местоположение, память, отключение режима энергосбережения);
- установить в настройках часов в смартфоне «Автоопределение времени» и уточнить расхождение со временем по GPS;
- можно установить в Настройки-Приложения-Уведомления-Важность-Среднее, чтобы видеть в строке уведомлений состояние приложения.

НАСТРОЙКИ ПРИЛОЖЕНИЯ BalloonLive:

The screenshot shows the 'Configuration' screen of the BalloonLive application. The settings are as follows:

- GPS Devices:** GPS CONFIGURATION
- Competition Configuration:**
 - Training:**
 - 1 (frequency of track recording, mandatory)
 - 10800 (+3 hours to UTC, optional)
 - Allow multiple marker drops (disabled, mandatory)
 - Allow multiple goal declarations (enabled)
 - Declaration format:** 4/4 (coordinate format, mandatory)
 - Altitude mode:** GPS Feet
 - Geodetic system:** UTM WGS84
- Pilot Configuration:**
 - 1 (competition number, mandatory)
 - Sergey (name, optional)
 - Domeni (surname, optional)

A green 'SAVE' button is located at the bottom of the screen.